

A man in a light blue shirt is seen from the side, holding a tablet. He is in a factory environment with industrial machinery and a clock in the background. Overlaid on the image are various digital graphics: a Siemens logo in the top right, a '24/7' circular icon, a 'NEWS' section with a person icon, a 'Home' button, and a network diagram with three people icons. The text 'Industry Online Support' is also visible.

SIEMENS

SIMIT Executable 3D Model SIMATIC Kinematics Integrator

SIMATIC S7-1500T / SIMATIC S7-PLCSIM Advanced
V4.0 SP1 HF1 / SIMIT V11

<https://support.industry.siemens.com/cs/ww/en/view/109802248>

Siemens
Industry
Online
Support



Legal information

Use of application examples

Application examples illustrate the solution of automation tasks through an interaction of several components in the form of text, graphics and/or software modules. The application examples are a free service by Siemens AG and/or a subsidiary of Siemens AG ("Siemens"). They are non-binding and make no claim to completeness or functionality regarding configuration and equipment. The application examples merely offer help with typical tasks; they do not constitute customer-specific solutions. You yourself are responsible for the proper and safe operation of the products in accordance with applicable regulations and must also check the function of the respective application example and customize it for your system.

Siemens grants you the non-exclusive, non-sublicensable and non-transferable right to have the application examples used by technically trained personnel. Any change to the application examples is your responsibility. Sharing the application examples with third parties or copying the application examples or excerpts thereof is permitted only in combination with your own products. The application examples are not required to undergo the customary tests and quality inspections of a chargeable product; they may have functional and performance defects as well as errors. It is your responsibility to use them in such a manner that any malfunctions that may occur do not result in property damage or injury to persons.

Disclaimer of liability

Siemens shall not assume any liability, for any legal reason whatsoever, including, without limitation, liability for the usability, availability, completeness and freedom from defects of the application examples as well as for related information, configuration and performance data and any damage caused thereby. This shall not apply in cases of mandatory liability, for example under the German Product Liability Act, or in cases of intent, gross negligence, or culpable loss of life, bodily injury or damage to health, non-compliance with a guarantee, fraudulent non-disclosure of a defect, or culpable breach of material contractual obligations. Claims for damages arising from a breach of material contractual obligations shall however be limited to the foreseeable damage typical of the type of agreement, unless liability arises from intent or gross negligence or is based on loss of life, bodily injury or damage to health. The foregoing provisions do not imply any change in the burden of proof to your detriment. You shall indemnify Siemens against existing or future claims of third parties in this connection except where Siemens is mandatorily liable.

By using the application examples you acknowledge that Siemens cannot be held liable for any damage beyond the liability provisions described.

Other information

Siemens reserves the right to make changes to the application examples at any time without notice. In case of discrepancies between the suggestions in the application examples and other Siemens publications such as catalogs, the content of the other documentation shall have precedence.

The Siemens terms of use (<https://support.industry.siemens.com>) shall also apply.

Security information

Siemens provides products and solutions with Industrial Security functions that support the secure operation of plants, systems, machines and networks.

In order to protect plants, systems, machines and networks against cyber threats, it is necessary to implement – and continuously maintain – a holistic, state-of-the-art industrial security concept. Siemens' products and solutions constitute one element of such a concept.

Customers are responsible for preventing unauthorized access to their plants, systems, machines and networks. Such systems, machines and components should only be connected to an enterprise network or the Internet if and to the extent such a connection is necessary and only when appropriate security measures (e.g. firewalls and/or network segmentation) are in place. For additional information on industrial security measures that may be implemented, please visit <https://www.siemens.com/industrialsecurity>.

Siemens' products and solutions undergo continuous development to make them more secure. Siemens strongly recommends that product updates are applied as soon as they are available and that the latest product versions are used. Use of product versions that are no longer supported, and failure to apply the latest updates may increase customer's exposure to cyber threats.

To stay informed about product updates, subscribe to the Siemens Industrial Security RSS Feed at: <https://www.siemens.com/industrialsecurity>.

Table of contents

Legal information	2
1 Introduction	4
1.1 Overview.....	4
1.2 Components used	4
2 Software Setup.....	5
2.1 SIMIT	5
2.1.1 Configuring the SIMIT-Unity coupling	5
2.1.2 Retrieve SIMIT project.....	5
2.1.3 Executable 3D model	6
2.1.4 PLCSIM Advanced coupling.....	7
2.1.5 Charts of the SIMIT project	8
2.2 TIA Portal	9
2.2.1 Preparing the TIA Portal project	9
3 Operating the digital twin.....	10
3.1 Starting the simulation.....	10
3.2 Overview of the 3D model	11
3.3 Manual control.....	12
3.3.1 Home	12
3.3.2 Jog.....	14
3.3.3 Teach and configure points	16
3.4 Operation.....	22
3.5 Programming pick and place.....	24
4 Appendix	37
4.1 Service and support	37
4.2 Industry Mall	38
4.3 Application support.....	38
4.4 Links and literature	38
4.5 Change documentation	38

1 Introduction

1.1 Overview

This application example can be used to simulate the SIMATIC S7-1500T SIMATIC Kinematics Integrator standard application with SIMATIC S7-PLCSIM Advanced and SIMIT in combination with a 3D model.

1.2 Components used

This application example has been created with the following hardware and software components:

Table 1-1

Component	Number	Article number
SIMATIC STEP 7 Professional V17 (TIA Portal)	1	6ES7822-1..06-..
PLCSIM Advanced 4.0 SP1 HF1	1	6ES7823-1F.03-0Y.5
SIMIT V11	1	6DL8913-0AL00-0AB5
SIMIT-Unity coupling V3.0.0	1	

This application example consists of the following components:

Table 1-2 Project components

Component	File name	Note
Documentation	Manual_SIMIT_Executable_3D_Model_SKI_V1_0_0.pdf	
STEP 7 project	TIA_Project_3D_Model_SKI_V1_0_0.zap17	Inside "TIA" folder
SIMIT project	SIMIT_Project_3D_Model_SKI_V1_0_0.zip	Inside "SIMIT" folder
3D Model	Executable_3D_Model_SKI_V1_0_0.zip	Inside "3D" folder
SIMIT-Unity coupling	Unity.zip	Inside "Unity" folder

2 Software Setup

After downloading the “SIMIT_Executable_3D_Model_SKI.zip”, it can be unzipped into a desired folder. All included files are shown in [Table 1-2](#).

2.1 SIMIT


NOTICE

It is important, that firstly the SIMIT-Unity coupling is configured in SIMIT before the SIMIT project is retrieved and opened for the first time.

2.1.1 Configuring the SIMIT-Unity coupling

The SIMIT-Unity coupling is based on an external coupling for SIMIT and must be added manually. The required steps are described in the following table.

Table 2-1



No.	Action
1.	<p>Unzip „Unity.zip“ into a new folder “Unity” in the following directory:</p> <p>...\\Siemens\\Automation\\SIMIT\\SIMIT SF\\couplings</p> <p>If the folder “couplings” does not exist yet, it needs to be created.</p>
2.	<p>Restart SIMIT to update the couplings dialogue. The new coupling “Unity” is visible in the coupling selection dialogue.</p> 
3.	<p>The SIMIT-Unity coupling was added correctly. The dialogue can be closed with clicking the “Cancel” button.</p>

2.1.2 Retrieve SIMIT project

Before retrieving the SIMIT project, the SIMIT-Unity coupling must be configured ([2.1.1](#)).

The SIMIT project is provided as a SIMIT archive. For retrieving the project following steps need to be done.

Table 2-2 Retrieve SIMIT project


No.	Action
1.	
2.	<p>Under "Archivename" navigate to "SIMIT_Project_3D_Model_SKI_V1_0_0.simarc". As "Target folder" a desired folder can be selected.</p> 
3.	The following warning can be confirmed with clicking "Yes".
4.	The project is retrieved.

2.1.3 Executable 3D model

Before starting the simulation, it is needed to add the 3D model into the project. Therefore, the following steps need to be done.

Table 2-3 Adding 3D model


No.	Action
1.	Unzip "Executable_3D_Model_SKI_V1_0_0.zip" into desired folder.
2.	Open existing coupling with double clicking "3DSKI".

No.	Action
3.	<p>To refresh the “Application Path”, click “Select application”, navigate to the folder from step 1, select “SKI” and click “Open”.</p> 
4.	Confirm the update of the signals with “Yes”.
5.	Check if the coupling is still defined as “Isochronous”.

2.1.4 PLCSIM Advanced coupling

Depending on whether the PLCSIM Advanced Virtual Ethernet Adapter should be used or not, the communication interface in the PLCSIM Advanced coupling needs to be set to “SOFTBUS” (when the PLCSIM Advanced Virtual Ethernet Adapter is **not** used) or to “TCPIP” (when the PLCSIM Advanced Virtual Ethernet Adapter is used).

Figure 2-1 Communication interface



Typically, when TIA Portal and SIMIT run on the same system, “SOFTBUS” is used.


2.1.5 Charts of the SIMIT project

The SIMIT simulation software maps the behavior of active components (e.g. of drives or valves). In SIMIT, you can simulate error scenarios to analyze the behavior of the machine in a virtual space. The required components are organized in individual charts.

pcPicker

This chart calculates the set point position for the axis of the picker base, because this axis is not controlled by the application.

Figure 2-2 Chart pcPicker



Drives

This folder consists of charts for all technology objects that are interconnected with a drive. For cyclic data exchange between the PLC and the drive, PROFIdrive telegram 105 is set up in these charts.

IOs


This folder consists of a chart, that does the interconnections between the in- and outputs of the application and the 3D model.

2.2 TIA Portal

2.2.1 Preparing the TIA Portal project

To prepare the provided TIA Portal archived project for the simulation, the following steps need to be done.

Table 2-4 Prepare TIA Portal project

No.	Action
1.	<p>Start TIA Portal, click “Project” and “Open”.</p> 
2.	Browse to the provided TIA Portal compressed project. Define a desired target folder.
3.	Start simulation of HMI.

3 Operating the digital twin



3.1 Starting the simulation

NOTE

It is important to go through chapter [2](#) before opening the SIMIT project and starting the simulation.

To start the simulation, following steps need to be done.


Table 3-1 Starting the simulation

No.	Action
1.	<p>Click „Start“ in SIMIT.</p> 
2.	<p>Confirm the appearing warning with „Ok“.</p> 
3.	<p>Simulation starts with following steps:</p> <ol style="list-style-type: none"> 1. Starting the S7-PLCSIM Advanced instance 2. Opening and connecting the 3D model 3. Establishing HMI connection
4.	<p>Digital twin is ready for operation.</p>

3.2 Overview of the 3D model

In the top left corner status information about the connection to SIMIT can be found (1). Products spawning at the smaller product belt (2) and are detected by a sensor (3). The Scara roboter (4) picks the products and sort them into a box (5), that is pushed by a loader (6) onto the bigger product belt (7). After 4 products are sorted into the box, the box is closed with a cover (8). The box is moved into the direction of the articulated arm (9) until a sensor (10) detects the box. With the palatizing the box onto the palette (11) the sequence is done. In parallel the next throughput has been started.


Figure 3-1 Overview of the 3D model



The “Space” key on the keyboard switches between 6 different standard views ([Table 3-2](#)).

3 Operating the digital twin

Table 3-2 Standard views







3.3 Manual control

3.3.1 Home

After the connection between the HMI and the PLC is established, it must be checked if the axes of the Scara roboter, conveyor belts and articulated arm are homed. Therefore, following steps must be done:

Table 3-3 Homing axes

No.	Action
1.	<p>Login as administrator: Username → admin Password → Admin</p> 
2.	<p>Select „Manual control“ and enable all axes.</p> 

No.	Action
3.	<p>Home all axes to 0,0° or rather 0,0mm.</p> 
4.	<p>Repeat step 2 and 3 for the articulated arm.</p> 



3.3.2 Jog



With SKI it is possible to jog a single axis or the kinematics at once:

- Jog a single axis (incremental / continuous) or jog to a target position
- Jog the kinematics (incremental / continuous), jog to a Cartesian target position or to a point from the point table with linear or sPTP motion

Therefore, following steps must be done:

Table 3-4 Jog

No.	Action
1.	<p>Login as administrator: Username → admin Password → Admin</p> 
2.	<p>Select „Manual control“ and enable all axes.</p> 

No.	Action
3.	<p>To jog a single axis, select “Axes” and for the desired type of jog command select the corresponding tab. After selecting the desired axis and defining the “Setpoint velocity” and the “Override”, the movement can be triggered.</p> 
4.	<p>To jog a kinematic, select “Kinematics” and for the desired type of jog command select the corresponding tab. After configuring the jog command (e.g. “Coordinate system”), defining the “Path velocity” and the “Override”, the movement can be triggered.</p> 

3.3.3 Teach and configure points

At the tab “Edit points” a list of points can be specified. These points can then be used as references in kinematics Motion Control commands when creating programs. This type of command specification has the advantage that points can be modified afterwards and the program is automatically updated by the reference.



A specific name can be assigned to each point, e.g. “place position”. You can change the points later to make adaptations. The point reference in the automatic program remains.


The points can be either defined by entering the coordinates manually or jogging the kinematics and saving its current position.

3 Operating the digital twin


As an example, follow these steps:



Table 3-5 Teach and configure points



No.	Action
1.	<p>Login as administrator: Username → admin Password → Admin</p> 
2.	<p>Select the first channel to control the Scara roboter.</p> 


No.	Action																																																						
3.	<p>Switch to "Configuration" and switch to the tab "Outputs". With selecting and deselecting "ProdStopperExtend" the stopper is extended. The corresponding input "ProdStopperExtended" is set.</p>  <table border="1"> <thead> <tr> <th>Address</th> <th>Status</th> <th>Name</th> </tr> </thead> <tbody> <tr> <td>200.0</td> <td>0</td> <td>ProdStopperExtend</td> </tr> <tr> <td>200.1</td> <td>0</td> <td>ProdStopperRetract</td> </tr> <tr> <td>200.2</td> <td>0</td> <td>ContLoaderExtend</td> </tr> <tr> <td>200.3</td> <td>1</td> <td>ContLoaderRetract</td> </tr> <tr> <td>200.4</td> <td>0</td> <td>StackLightGreen</td> </tr> <tr> <td>200.5</td> <td>0</td> <td>StackLightOrange</td> </tr> <tr> <td>200.6</td> <td>1</td> <td>StackLightRed</td> </tr> <tr> <td>200.7</td> <td>0</td> <td>GripperGrip</td> </tr> </tbody> </table>   <table border="1"> <thead> <tr> <th>Address</th> <th>Status</th> <th>Name</th> </tr> </thead> <tbody> <tr> <td>200.4</td> <td></td> <td>ScaraHwLimitA1Min</td> </tr> <tr> <td>200.5</td> <td></td> <td>ScaraHwLimitA2Max</td> </tr> <tr> <td>200.6</td> <td></td> <td>ScaraHwLimitA2Min</td> </tr> <tr> <td>200.7</td> <td></td> <td>ScaraHwLimitA3Max</td> </tr> <tr> <td>201.0</td> <td></td> <td>ScaraHwLimitA3Min</td> </tr> <tr> <td>202.2</td> <td></td> <td>ProdBeltOccupiedSensor</td> </tr> <tr> <td>202.3</td> <td>1</td> <td>ProdStopperExtended</td> </tr> <tr> <td>202.4</td> <td></td> <td>ProdStopperRetracted</td> </tr> </tbody> </table>	Address	Status	Name	200.0	0	ProdStopperExtend	200.1	0	ProdStopperRetract	200.2	0	ContLoaderExtend	200.3	1	ContLoaderRetract	200.4	0	StackLightGreen	200.5	0	StackLightOrange	200.6	1	StackLightRed	200.7	0	GripperGrip	Address	Status	Name	200.4		ScaraHwLimitA1Min	200.5		ScaraHwLimitA2Max	200.6		ScaraHwLimitA2Min	200.7		ScaraHwLimitA3Max	201.0		ScaraHwLimitA3Min	202.2		ProdBeltOccupiedSensor	202.3	1	ProdStopperExtended	202.4		ProdStopperRetracted
Address	Status	Name																																																					
200.0	0	ProdStopperExtend																																																					
200.1	0	ProdStopperRetract																																																					
200.2	0	ContLoaderExtend																																																					
200.3	1	ContLoaderRetract																																																					
200.4	0	StackLightGreen																																																					
200.5	0	StackLightOrange																																																					
200.6	1	StackLightRed																																																					
200.7	0	GripperGrip																																																					
Address	Status	Name																																																					
200.4		ScaraHwLimitA1Min																																																					
200.5		ScaraHwLimitA2Max																																																					
200.6		ScaraHwLimitA2Min																																																					
200.7		ScaraHwLimitA3Max																																																					
201.0		ScaraHwLimitA3Min																																																					
202.2		ProdBeltOccupiedSensor																																																					
202.3	1	ProdStopperExtended																																																					
202.4		ProdStopperRetracted																																																					

3 Operating the digital twin

No.	Action
4.	<p>Switch to "Manual control", select "ProdBelt" and enable the axis.</p> 

No.	Action
5.	<p>Select "Axes" and jog the belt until the first product reaches the stopper. The corresponding input signal "ProdBeltOccupiedSensor" is set.</p>  

No.	Action
6.	<p>Switch to "Edit points", select the point "AbPickProduct", switch to the tab "Approach point" and move the Scara roboter to the selected point.</p> 
7.	<p>Use the "Space" key on the keyboard, switch to the shown standard view:</p> 



No.	Action
8.	<p>Switch to the tab "Teach point" and select the point "AbPlaceProduct". Move the zAxis in negative z direction until the gripper touches the product. The press "Save point". It could be useful to reduce the "Override".</p> 
9.	<p>Select the point "AbPickProduct" again, switch to the tab "Approach point" and move the Scara roboter to the selected point.</p>


3.4 Operation

This application example provides a sequence for continuous operation, where both robots are involved (3.2). To start this sequence, following steps needs to be done:

3 Operating the digital twin

Table 3-6 Continuous operation

No.	Action
1.	<p>Select the channel of the articulated arm and press “Initialize program” until the axes stop automatically. Then press “Start” and the continuous operation of the articulated arm will start when the first box is detected by the input “ContAtPalletizingSensor”.</p> 
2.	<p>Select the channel of the Scara roboter and press “Initialize program” until the axes stop automatically. Then press “Start” and the continuous operation of the Scara roboter will start with detecting a product at the input “ProdBeldOccupiedSensor”.</p> 


No.	Action
3.	<p>The sequence is running automatically, until the palette is filled with 6 boxes. Then a message on the channel of the articulated arm occurs. With confirming this message, the palette is emptied and the sequence goes on.</p> 

3.5 Programming pick and place

The program editor can be used to create a completely new program or to adapt an existing program.

1. The command list is displayed on the left side. It displays a section of up to ten configured commands of the selected program slot. To select a command the corresponding line must be pressed.
2. The command bar includes different commands to structure the program and move the axes. The commands are described in the following chapters.
3. The displayed program slot can be selected by pressing the right or left arrow buttons.

Figure 3-2: Overview program editor



To insert a command, select a command line from the program and choose a command from the command bar that can be added. After saving the changes of the command configuration the command is inserted. To edit an already configured command, select it in the table and then press the 'Edit command' button.


To modify the command list, the user can access additional auxiliary functions, such as copy and paste, delete, or deactivate a command. These functions are grouped in a separate submenu. To open this editing menu, any line at the program list must be pressed for at least 3 seconds.

Programming example




In the following table the programming of a Pick and Place is explained step by step. If you want to follow the instructions, you can use the provided project as a basis. Delete the program slot 3 in the 1st channel by clicking on the 'Trash can' icon and selecting 'Delete program slot'. Now you can program the Pick and Place yourself.

After you have programmed the example below the Scara will pack one product in each box.

Table 3-7 Pick & Place

No.	Action
1.	<p>Create and insert a new label 'PICK & PLACE' in the program slot 3 in the 1st channel.</p>  <p>Result:</p> <pre>*** PICK & PLACE ***</pre>


3 Operating the digital twin

No.	Action
2.	<p>Add a kinematics movement command: sPTP to the point 'AbPickProduct'. Open the kinematics movements commands. sPTP is already selected. Click on 'Point table'. Select the point from the point table. Set the command transition to 'Next cycle' and save the command.</p>  <p>Result:</p> 
3.	<p>Add a wait command: Wait until a product is ready to be picked '%I ProdBeltOccupiedSensor' = TRUE</p> 

3 Operating the digital twin

No.	Action
	<div data-bbox="470 275 1332 716"> </div> <p>Result:</p> <div data-bbox="470 772 1332 817"> </div>
4.	<p>Add a kinematics movement command: Move linear to the point 'PickProduct'. In the configuration of the kinematics command select 'Linear motion' and 'Point table'. Choose the point from the point table. Configure the blending to 'Max.'.</p> <div data-bbox="470 929 1332 1713"> </div> <p>Result:</p> <div data-bbox="470 1758 1332 1803"> </div>
5.	<p>Add 2 commands: Activate the gripper by setting '%Q GripperGrip' = TRUE and '%Q GripperRelease' = FALSE. Set the command transition to 'Immediately'.</p>

3 Operating the digital twin

No.	Action
	<div data-bbox="470 264 737 586"> <p>Insert command</p>  </div> <div data-bbox="470 600 737 1048"> <p>Outputs</p> <ul style="list-style-type: none"> %Q 200.0: ProdStopperExtend %Q 200.1: ProdStopperRetract %Q 200.2: ContLoaderExtend %Q 200.3: ContLoaderRetract %Q 200.4: StackLightGreen %Q 200.5: StackLightOrange %Q 200.6: StackLightRed %Q 200.7: GripperGrip %Q 201.0: GripperRelease %Q 0.0: Output 10 </div> <div data-bbox="758 600 1348 1048"> <p>Select an output and specify the control value.</p> <p>Set output Set condition Set variable Increment variable</p> <p>GripperGrip = TRUE</p> <p>Command transition: Next cycle, Immediately</p> <p>Save changes</p> </div> <div data-bbox="470 1075 737 1523"> <p>Outputs</p> <ul style="list-style-type: none"> %Q 200.0: ProdStopperExtend %Q 200.1: ProdStopperRetract %Q 200.2: ContLoaderExtend %Q 200.3: ContLoaderRetract %Q 200.4: StackLightGreen %Q 200.5: StackLightOrange %Q 200.6: StackLightRed %Q 200.7: GripperGrip %Q 201.0: GripperRelease %Q 0.0: Output 10 </div> <div data-bbox="758 1075 1348 1523"> <p>Select an output and specify the control value.</p> <p>Set output Set condition Set variable Increment variable</p> <p>GripperRelease = FALSE</p> <p>Command transition: Next cycle, Immediately</p> <p>Save changes</p> </div> <div data-bbox="470 1541 1348 1713"> <p>Result:</p> <pre> [3 4] Set %Q GripperGrip = TRUE [3 5] Set %Q GripperRelease = FALSE </pre> </div>
6.	Add a wait command: Wait for the feedback %I GripperGripped = TRUE.

3 Operating the digital twin

No.	Action
	<div><div><div>Inputs</div><div><div>%I 202.4: ProdStopperRetracted</div><div>%I 202.5: ContPackingSensor</div><div>%I 202.7: ContLoaderExtended</div><div>%I 203.0: ContLoaderRetracted</div><div>%I 203.1: GripperGripped</div><div>%I 203.3: ProductSpa</div><div>%I 203.4: ContainerSpawnsenso</div><div>%I 202.6: ContAtPalletizingSen</div><div>%I 0.0: Input 20</div><div>%I 0.0: Input 21</div></div></div><div><div>Select an input from the table and specify a condition to continue the program.</div><div><div>Command</div><div><div>Input</div><div>Output</div><div>Condition</div><div>Variable</div><div>Waiting time</div></div></div><div><div>Continue program if</div><div><div>GripperGripped</div><div>=</div><div>TRUE</div></div></div><div><div>Save changes</div></div></div></div> <div><div>Result:</div><div><div>[3 6] Wait for %I GripperGripped = TRUE</div></div></div>
7.	<div><div>Add a kinematics movement command: Move linear to the point 'AbPickProduct'. Set the command transition to 'Next cycle'.</div><div><div><div>Point table</div><div><div>HomePos</div><div>PickProduct</div><div>AbPickProduct</div><div>AbPlaceProduct</div><div>PlaceProduct</div><div>PickCover</div><div>AbPickCover</div><div>PlaceCover</div><div>AbPlaceCover</div></div></div><div><div>Single command</div><div><div>Command</div><div><div>sPTP motion</div><div>Linear motion</div><div>Interrupt & Continue</div><div>Stop</div><div>Change tool</div></div></div><div><div>Target specification</div><div><div>Manual</div><div>Point table</div><div>Variables</div></div></div><div><div>Target position</div><div><div>x</div><div>+354.618</div><div>mm</div><div>A</div><div>+0.000</div><div>°</div></div><div><div>y</div><div>-562.605</div><div>mm</div></div><div><div>z</div><div>+980.000</div><div>mm</div></div></div><div><div>Coordinate system</div><div><div>WCS</div><div>OCS1</div><div>OCS2</div><div>OCS3</div></div></div><div><div>Coordinates type</div><div><div>Absolute</div><div>Relative</div></div></div><div><div>Blending</div><div><div>OFF</div><div>Max.</div></div></div><div><div>Command dynamics</div><div><div>Default</div><div>Max.</div></div></div><div><div>Command transition</div><div><div>Command done</div><div>Next cycle</div></div></div><div><div>Save changes</div></div></div></div><div><div>Result:</div><div><div>[3 7] Move linear to AbPickProduct</div></div></div></div>
8.	<div><div>Add a kinematics movement command: sPTP to the point 'AbPlaceProduct'. Set the command transition to 'Next cycle' and configure the Blending as 'Max.'.</div></div>

3 Operating the digital twin

No.	Action
	<div> <div> Point table <ul style="list-style-type: none"> HomePos PickProduct AbPickProduct AbPlaceProduct PlaceProduct PickCover AbPickCover PlaceCover AbPlaceCover </div> <div> <div>Single command</div> <div>Path segment</div> <div> <div>Command</div> <div>sPTP motion</div> <div>Linear motion</div> <div>Interrupt & Continue</div> <div>Stop</div> <div>Change tool</div> </div> <div> <div>Target position</div> <div>Manual</div> <div>Point table</div> <div>Variables</div> </div> <div> <div>Target position</div> <div>x</div> <div>+631,673</div> <div>mm</div> <div>A</div> <div>+0,000</div> <div>°</div> </div> <div> <div>y</div> <div>-93,598</div> <div>mm</div> </div> <div> <div>z</div> <div>+980,000</div> <div>mm</div> </div> <div> <div>Coordinate system</div> <div>WCS</div> <div>OCS1</div> <div>OCS2</div> <div>OCS3</div> <div>MCS</div> </div> <div> <div>Coordinates type</div> <div>Absolute</div> <div>Relative</div> </div> <div> <div>Blending</div> <div>OFF</div> <div>Max.</div> </div> <div> <div>Dynamics factor</div> <div>Default</div> <div>Max.</div> </div> <div> <div>Command transition</div> <div>Command done</div> <div>Next cycle</div> <div>Save changes</div> </div> </div> </div>

Result:

[3 | 8] sPTP to AbPlaceProduct

50.0%




max

3 Operating the digital twin

No.	Action
	<div data-bbox="469 277 1350 725"> <p>Variables</p> <ul style="list-style-type: none"> START program PAUSE program CONTINUE program STOP program FAST STOP program CYCLE STOP program ContReady ContLoaded ContPacked ContMoving <p>Select a variable from the variable list and specify a condition to continue the program.</p> <p>Command: Input Output Condition Variable Waiting time</p> <p>Continue program if</p> <p>ContReady = TRUE</p> <p>Variable state after command execution: keep invert set reset</p> <p>Save changes</p> </div> <p>Result:</p> <ul style="list-style-type: none"> [3 9] Wait for ContPacked = FALSE [3 10] Wait for ContMoving = FALSE [3 11] Wait for ContReady = TRUE
10.	<p>Add a kinematics movement command: Move linear to the point 'PlaceProduct'.</p> <div data-bbox="469 1016 1350 1464"> <p>Point table</p> <ul style="list-style-type: none"> HomePos PickProduct AbPickProduct AbPlaceProduct PlaceProduct PickCover AbPickCover PlaceCover AbPlaceCover <p>Single command</p> <p>Command: sPTP motion Linear motion Interrupt & Continue Stop Change tool</p> <p>Target specification: Manual Point table Variables</p> <p>Target position:</p> <ul style="list-style-type: none"> x: +631.673 mm y: -93.598 mm z: +868.414 mm <p>Coordinate system: WCS OCS1 OCS2 OCS3</p> <p>Coordinates type: Absolute</p> <p>Blending: OFF</p> <p>Command dynamics: Default</p> <p>Command transition: Command done Next cycle</p> <p>Save changes</p> </div> <p>Result:</p> <ul style="list-style-type: none"> [3 12] Move linear to PlaceProduct
11.	<p>Add commands to deactivate the gripper: Deactivate the gripper by setting '%Q GripperGrip' = FALSE and '%Q GripperRelease' = TRUE. Set the command transition to 'Immediately'.</p>

No.	Action
	<div> <div> Outputs <ul style="list-style-type: none"> %Q 200.0: ProdStopperExtend %Q 200.1: ProdStopperRetract %Q 200.2: ContLoaderExtend %Q 200.3: ContLoaderRetract %Q 200.4: StackLightGreen %Q 200.5: StackLightOrange %Q 200.6: StackLightRed %Q 200.7: GripperGrip %Q 201.0: GripperRelease %Q 0.0: Output 10 </div> <div> <p>Select an output and specify the control value.</p> <p>Set output Set condition Set variable Increment variable</p> <p>GripperGrip = FALSE</p> <p>Command transition: Next cycle, Immediately</p> <p>Save changes</p> </div> </div> <div> Outputs <ul style="list-style-type: none"> %Q 200.1: ProdStopperRetract %Q 200.2: ContLoaderExtend %Q 200.3: ContLoaderRetract %Q 200.4: StackLightGreen %Q 200.5: StackLightOrange %Q 200.6: StackLightRed %Q 200.7: GripperGrip %Q 201.0: GripperRelease %Q 0.0: Output 10 %Q 0.0: Output 11 <p>Select an output and specify the control value.</p> <p>Set output Set condition Set variable Increment variable</p> <p>GripperRelease = TRUE</p> <p>Command transition: Next cycle, Immediately</p> <p>Save changes</p> </div> <p>Result:</p> <pre> 1 [3 13] Set %Q GripperGrip = FALSE ↓ 1 [3 14] Set %Q GripperRelease = TRUE ↓ </pre>
12.	<p>Add a wait command: Wait for the feedback %I GripperGripped = FALSE.</p> <div> <div> Inputs <ul style="list-style-type: none"> %I 202.4: ProdStopperRetracted %I 202.5: ContPackingSensor %I 202.7: ContLoaderExtended %I 203.0: ContLoaderRetracted %I 203.1: GripperGripped %I 203.3: ProductSpa %I 203.4: ContainerSpawnsenso %I 202.6: ContAtPalletizingSen %I 0.0: Input 20 %I 0.0: Input 21 </div> <div> <p>Select an input from the table and specify a condition to continue the program.</p> <p>Command: Input Output Condition Variable Waiting time</p> <p>Continue program if: GripperGripped = FALSE</p> <p>Save changes</p> </div> </div> <p>Result:</p>

No.	Action
13.	<p>Add a kinematics movement command: Move linear to the point 'AbPlaceProduct'.</p> <p>Result:</p>
14.	<p>Add a Jump command: Jump to the label APPLY COVER.</p> <p>Result:</p>
15.	<p>Insert a Jump command after the initialization routine in program slot 0. After the command 'Wait for START program = TRUE' and starting the parallel sequences</p>

No.	Action
	<p>insert a jump to the Label 'PICK & PLACE'.</p>  <p>Result:</p> 
16.	<p>Insert a Jump command to the Label 'PICK & PLACE' after the 'APPLY COVER' segment in program slot 4. That way the program will loop through packing a product in a container and then applying the cover.</p>  <p>Result:</p>

No.	Action
	<div data-bbox="470 280 1348 716"> <div>*** APPLY COVER ***</div> <div>Program slot 4</div> <div>[4 1] sPTP to AbPickCover 20.0% max</div> <div>[4 2] Move linear to PickCover</div> <div>⋮</div> <div>[4 15] Jump to STOP PROGRAM if CYCLE STOP program = TRUE</div> <div>[4 16] Jump to PICK & PLACE</div> <div>Program end</div> </div>
17.	<p data-bbox="470 750 1348 806">Save the program by clicking 'Save changes' on the bottom right corner of the program editor.</p> <div data-bbox="470 828 1348 1265"> <div>*** PICK & PLACE ***</div> <div>[3 1] sPTP to AbPickProduct 50.0%</div> <div>[3 2] Wait for %I ProdBeltOccupiedSensor = TRUE</div> <div>[3 3] Move linear to PickProduct max</div> <div>[3 4] Set %Q GripperGrip = TRUE</div> <div>[3 5] Set %Q GripperRelease = FALSE</div> <div>[3 6] Wait for %I GripperGripped = TRUE</div> <div>[3 7] Move linear to AbPickProduct 50.0% max</div> <div>[3 8] sPTP to AbPlaceProduct</div> <div>[3 9] Wait for ContPacked = FALSE</div> <div> <div>Program name</div> <div>Program slot 3</div> <div>Insert command</div> <div>Edit command</div> <div>Save changes</div> </div> </div>

4 Appendix

4.1 Service and support

Industry Online Support

Do you have any questions or need assistance?

Siemens Industry Online Support offers round the clock access to our entire service and support know-how and portfolio.

The Industry Online Support is the central address for information about our products, solutions and services.

Product information, manuals, downloads, FAQs, application examples and videos – all information is accessible with just a few mouse clicks:

support.industry.siemens.com

Technical Support

The Technical Support of Siemens Industry provides you fast and competent support regarding all technical queries with numerous tailor-made offers – ranging from basic support to individual support contracts.

Please send queries to Technical Support via Web form:

siemens.com/SupportRequest

SITRAIN – Digital Industry Academy

We support you with our globally available training courses for industry with practical experience, innovative learning methods and a concept that's tailored to the customer's specific needs.

For more information on our offered trainings and courses, as well as their locations and dates, refer to our web page:

siemens.com/sitrain

Service offer

Our range of services includes the following:

- Plant data services
- Spare parts services
- Repair services
- On-site and maintenance services
- Retrofitting and modernization services
- Service programs and contracts

You can find detailed information on our range of services in the service catalog web page:

support.industry.siemens.com/cs/sc

Industry Online Support app

You will receive optimum support wherever you are with the "Siemens Industry Online Support" APP. The app is available for iOS and Android:

support.industry.siemens.com/cs/ww/en/sc/2067

4.2 Industry Mall



The Siemens Industry Mall is the platform on which the entire Siemens Industry product portfolio is accessible. From the selection of products to the order and the delivery tracking, the Industry Mall enables the complete purchasing processing – directly and independently of time and location:

mall.industry.siemens.com

4.3 Application support

Siemens AG
Digital Factory Division
Factory Automation
Production Machines
DI FA PMA APC
Frauenauracher Str. 80
91056 Erlangen, Germany

mailto: tech.team.motioncontrol@siemens.com

4.4 Links and literature

Table 4-1

No.	Topic
\1\	Siemens Industry Online Support https://support.industry.siemens.com
\2\	Link to this entry page of this application example https://support.industry.siemens.com/cs/ww/en/view/109802248
\3\	SIMATIC SIMIT Simulation Platform https://support.industry.siemens.com/cs/ww/de/view/109746429
\4\	SIMIT-Unity coupling https://support.industry.siemens.com/cs/ww/de/view/109769816

4.5 Change documentation

Table 4-2

Version	Date	Modifications
V1.0	12/2022	First version